

Assembly Guide

Before assembling your chair, watch an assembly video at: www.kyotamassagechairs.com/assembly-tutorials


Alternatively, scan the QR code to go directly to the URL above.



Step 1:


Carefully check the accessory box contents and make sure all items are accounted for.

If anything is missing, please contact Kyota Massage Chairs at (603) 910-5333. Do not return to the place of purchase.



Step 2:

Slide the top of the box and lift upwards. The chair will be positioned in the box with its footrest up.




Kiyomi[®] M698 **4D Massage Chair**




72 Stard Road, Seabrook, NH 03874 | (603) 910-5333 | www.kyotamassagechairs.com Version 1.0


Step 8: Locate the zippers on the front and sides of the seat pad. To secure the zippers, align them and zip them up.






Step 3: Remove the packaging materials and the protective cover over the chair.






Packaging materials Protective covering








Step 9:

Plug the power cord into the back of the chair, plug the other side into a grounded 110v outlet. Press the power switch to "I" (on).


The tablet will power on showing a yellow warning screen. Tap to confirm safety warning.






Step 6:

Locate the tablet holder and the tablet remote. Remove the cover from the arm panel revealing 3 screws. Use the Screwdriver to unscrew the screws. Place the tablet holder onto the platform, re-screw each of the 3 screws back into place. Gently clip the cover into place over the screws.



Step 7: Attach the tablet cord to the connection port on the left side of the chair seat. Be careful to line up the pins and key, then push together when aligned — do not force.



Now, press an auto program on the tablet remote.



If you wish to use an APP to control the chair, download "Kyota Kiyomi M698" from the Apple or Google app store and follow pairing instructions found within the APP.

Review chair for smooth operation. If things are not operating correctly, review all assembly steps. Call Kyota support at (603) 910-5333 if you need live US-based support.

You are done; time for a Massage!



Register your product at www.kyotamassagechairs.com/ warranty/registration to ensure it is in our system. This will simplify the warranty process should you ever need it.

Alternatively, **scan the QR code** to go directly to the URL above.