

You will be taken to the Body Scanning screen each time you start a massage session. The scan will measure your body specifics. Sit back and relax.



Note: If you tap "Cancel Body Scan" the scan will immediately stop. The massage selected will begin. The back massager will run the entire length of the track which may result in the massage nodes reaching above your neck causing discomfort. We always recommend a full body scan unless you are exclusively using Point or Partial mode in Manual.

After scanning, you can fine tune the height of the massage nodes using the "+"&"-" buttons if needed. Tap OK to confirm.



After confirming, you will be taken to the In-use screen below where you can observe all current settings and session information.



name "Manual."

Auto Programs

From the home display, tap the AUTO button to enter Auto Program Menu. Choose from Stretch, Chinese, Renewal, Pain Relief, Yoga, Recharge, Siesta, Rocking, Sleep, Fatigue, Recovery, Deep Relief, Revival, Easy Care, Gentle, Sports, Mental Wellness, Neck & Shoulders, Back Relief, Hip & Waist, Leg & Foot, or Demo. You may also tap the top navigation which has been circled to reach the auto program menu as well.



Share a photo and tag us:



X @infinity_chairs

@Infinitymassagechairs

Don't forget to use #lovemyinfinitychair

INFINITY

72 Stard Road, Seabrook, NH 03874 603-910-5000 www.infinitymassagechairs.com Version 1.1



display screen to be always on or time out.

