




TrueFit® Body Scan

Choose an auto program, you will be taken to the **Body Scanning Screen**. Here you can use the “+” and “-” to adjust the back mechanism up and down to match your specific shoulder height. Alternatively, tap the “OK” button when your shoulder position is correct.




Once the body scan is finished, you will be brought to the controls screen and your massage program will start. Use this screen to further customize your massage, if desired.

Bluetooth® Speakers

Immersive speakers located in the headrest connect to a phone or other Bluetooth® device allowing you to stream music, guided meditations, ambient soundscapes, and any other form of audio to enhance the mental experience of your massage.

Activate Bluetooth by tapping the **System** button. Next, locate the Bluetooth button and tap to “ON”. Open your Bluetooth settings on your device and find “Solstice Deluxe”, then pair together.



Share a photo and tag us:

@Infinitymassagechairs

@infinity_chairs

@Infinitymassagechairs

Don't forget to use #lovemyinfinitychair

INFINITY®

72 Stard Road, Seabrook, NH 03874
603-910-5000
www.infinitymassagechairs.com
Version 1.0

INFINITY®


MESSAGE CHAIRS

Quick Start Guide


Solstice® Deluxe Massage Chair




Alternatively, scan the QR code to watch a remote tutorial video.



Auto Programs – Choose from 12 unique and pre-choreographed auto programs.





Auto Program Display – After choosing an auto program, you will be taken to this screen where you can adjust air intensity, roller speed, lumbar heat, air zone, and increase or decrease the amount of minutes during your massage.



Air Settings – Customize your air massage experience by selecting your preferred air zone: Full Body, Upper Body, Lower Body, or turn it Off. To fine-tune the intensity, simply tap to adjust the air intensity to your ideal comfort level.

INFINITY®

Home Screen – After turning on your chair, this is the first screen you will see on your touch screen tablet. Use this screen to navigate all menu options. To select, simply tap the screen with your finger.



Adjustment – The tablet will guide you to the Adjustment screen, where you can effortlessly personalize the footrest, backrest, and recline angles—enhancing every moment of your massage experience.



Manual Settings – Looking for more control? Access the Manual Settings to fine-tune your massage just the way you like it.



Manual – Need extra relief in one spot? Switch to manual mode to fully customize your massage and target problem areas.



System – Personalize your chair's core settings to match your preferences. Here, you can adjust the voice demo, sleep mode, Bluetooth® connectivity, language, voice volume, beep sounds, and screen brightness—all designed to enhance your overall experience.