


Step 3: Remove plastic coverings from the chair. Inspect the chair and make sure that there's no damage to the chair or its accessories.



Step 1: Open the box and remove the packaging materials.




SCAN CODE

Before assembling your chair, watch an assembly video at: www.infinitymassagechairs.com/assembly-tutorials
Alternatively, scan the QR code to go directly to the URL above.

INFINITY
MASSAGE CHAIRS


Assembly Guide

**Solstice® Deluxe
Massage Chair**




Step 4: With a partner, lift the box and position the massage chair out of the box and position on a flat surface.


Step 2: Prior to assembly, carefully unpack accessories box. Check the box to make sure all the contents are accounted for.
If anything is missing, please contact INFINITY at 603-910-5000. Do not return to the place of purchase.



Final Check:



Power on the controller and select a program to start a session.



Review chair for smooth operation. If things are not operating correctly, review all assembly steps. Call Infinity support at 1-603-910-5000 if you need live US-based support.

You are done; time for a Massage!



SCAN CODE

Register your product at www.infinitymassagechairs.com/warranty to ensure it is in our system. This will simplify the warranty process should you ever need it.

Alternatively, scan the QR code to go directly to the URL above.


INFINITY

72 Stard Road, Seabrook, NH 03874
(603) 910-5000
www.infinitymassagechairs.com
Version 1.0


INFINITY

MASSAGE CHAIRS


- 4 Step 4:** Locate the accessories box, take out the power cord, touch screen tablet, and tablet holder. Lower the footrest down from the chair body into its resting position.



- 5 Step 5:** Locate the tablet holder and screw into the right arm panel until its tight. Position the tablet style controller into the bottom of the tablet holder, then clip the top into place. Hold the tablet's receiver plug and align the key & pins to the receiver end on the side of the seat. Gently push in, then screw the fastener ring to secure.



- 6 Step 6:** Locate the zippers on the bottom of the seat pad, there is one on each side and one in the front, align them and zip until the seat pad is secured. Tuck the tablet style controller's cord in between the seat.



- 7 Step 7:** Connect the chair's power cord into a grounded 120V electrical outlet and plug it into the back side of the base of the chair. Flip the main power switch (I/O) to on (I).

