



Start an Auto Program

Sit comfortably with your head against the headrest and your back fully against the backrest. Select an Auto Program to begin the TrueFit® Body Scan.



The massage rollers will scan your back and detect your shoulder position. After the scan, use the **shoulder position adjustment** controls, if needed, to align the massage mechanism to the top of your shoulders.



Once the TrueFit® Body Scan is complete, you will be taken to the controls allowing you to make specific adjustments to your **Auto Program** massage session.



Quick Access Control Panel

Use the quick access control panel to quickly jump into an auto program, adjust zero gravity, incline/recline of the backrest, legrest up/down, and/or utilizing the USB-C charging port.

Power Button

Press and hold to turn the Massage Chair on/off. Auto Programs will display on screen.

Smart Dial

Turn clockwise or counter-clockwise to choose your preferred auto program.

Zero Gravity

Press to cycle through 3 Zero Gravity angles.

Backrest Up/Down

Press to incline or recline the backrest.

Legrest Up/Down

Press to move the legrest up or down.

USB-C Port

Charge your favorite compatible device by plugging in to the port.

Share a photo and tag us:

@Infinitymassagechairs

@infinity_chairs

@Infinitymassagechairs

Don't forget to use #infinitymassagechairs

INFINITY®

72 Stard Road, Seabrook, NH 03874
603-910-5000

www.infinitymassagechairs.com

Version 1.1

INFINITY®


MASSAGE CHAIRS

Quick Start Guide


Serenza™ Flex 4D Massage Chair




Alternatively, scan the QR code to watch a remote tutorial video.



Auto - Select a category to see specific programs or swipe left and right to scroll. Tap your program of choice to start.




Manual - Take control to manually build a massage sequence. Selections are available in each of the 4 tabs to the right.




SootheMe® - Choose from 10 relaxing sounds to enhance your massage. Tap to select a sound, then tap again to turn it off. Adjust the volume using the tablet's side buttons or the speaker icon in the top right navigation.

INFINITY®



Home Screen - The main screen when the massage chair turns on. Here you will find access to all the chairs functions.




Bottom Navigation Functions


Media - Tap to access a Google Browser, YouTube, Netflix or HBO/Max. (Subscriptions are required for Netflix and HBO/Max)

Adjustments - Tap to turn/change Lumbar Heat, Foot Heat, Foot Roller, Calf Kneading & Oscillation, and Chair Adjustments.


Air Settings - Tap to change Airbag Regions and Air Intensity.



MyMemory® - Access up to 6 saved massage sessions here. Tap to run or tap the star to delete from memory.




Extra Functions - Change functions such as Sleep Mode, Voice Demo, Voice Listening, and LED Light.




Settings - Ensure Chair Connection is ON and connected to **Serenza Flex 4D**. If the chair name is blank, select **Serenza Flex 4D** and tap Confirm to reconnect. Connect to Wi-Fi for Media features. The top navigation Bluetooth icon controls speaker connections, this control and the Chair Connection must also be on for the Speakers to work.

III. Connecting the Massage Chair (APP & Chair Connection)

1. Enter Setting:
From the main interface of the APP, tap to enter **[Setting]**




2. Enable Connection: Turn on the Chair Connection slider. If Serenza Flex does not appear, select it from the black list below and tap Confirm.



3. Automatic Pairing: When the gray box under Chair Connection shows **Serenza Flex** the chair is connected. Tap "Confirm" to finalize the chair and network pairing.

You're Ready to Begin

Your touch screen tablet is now configured and ready to use. Continue to the **Quick Start Guide** to learn how to select an Auto Program, complete a TrueFit® Body Scan, and begin enjoying a personalized massage experience.



Enjoy your Massage!

INFINITY®

72 Stard Road, Seabrook, NH 03874
603-910-5000
www.infinitymassagechairs.com
Version 1.0

INFINITY®

MASSAGE CHAIRS

Initial Tablet Set-Up

Serenza™ Flex 4D Massage Chair

I. Powering On & Launching the APP


1. Device Power-On:
Make sure the power switch in the back of the chair is **ON**. Press and hold the **[Power Button]** on the side of the tablet until the tablet display turns on.



2. Automatic Booting:
Once the system finishes loading, it will automatically launch the **Serenza Flex 4D** control application.




3. Safety Warning Confirmation:
Please read the **Safety Warning** pop-up's on the screen carefully. Tap **[Confirm]** after reading each, to enter the main operation interface.




II. Initial Network & Bluetooth Setup


1. Activate Control Center:
Gently **[swipe down twice]** from the top of the screen with your finger to expand the system's quick settings panel.




2. Select Your Wireless Network:
Tap the **[Internet]** icon, then choose your wireless network.



3. Connect to Wi-Fi:
Enter your password, then tap "Done" to close the pop-up.



4. Bluetooth Switch: Tap the **Bluetooth** icon and confirm that the **Use Bluetooth** switch is turned on. If the tablet is not already connected to the chair, select **Serenza Flex** from the available devices to pair it. Then tap "Done".



5. Return to Operation Interface:
Once settings are complete, **[swipe up]** on the screen to hide the control center and return to the APP interface.

