

In-Use Screen

After a Massage program is selected, the In-Use screen displays all settings to that program.



- 1

Status Icons
- 2

Position & Direction
- 3

Settings
- 4


Running Program
- 5

Play/Pause/Home
- 6

Sleep Mode
- 7

More Options

Voice Commands List



The Voice Commands listing can be found under System from the Home menu. Control your chair and massage experience completely hands-free by using one of the many voice commands. **To activate, say the phrase “Hey Kyota” or “Hi Kyota.”**

Kyota is pronounced:
“Key-Oh-Ta”

Quick Access Panel + Dial & Button Control

The Quick Access Panel + Dial & Button Control allows you to change massage settings and options.



Dial & Button Control:


- Press & hold power button turns massage chair on/off.
- Turn the dial left to incline the chair, turn the dial right to recline the chair.
- Quickly press power button cycles through ALL auto programs. Name of program is shown on tablet.

- Smart Massage** - Press to turn on/off the Smart Massage
Rocking - Press to turn on/off the Rocking Feature
Heat - Press to turn on/off Back & Calf Heat
Foot Roller - Press to turn on/off Foot Rollers
Airbags - Press to turn on/off Airbags
ZeroG - Press to turn on/off Zero Gravity
Waist Cooling - Press to turn on/off Cooling
Sleep Mode - Press to turn on/off Sleep Mode

KYOTA | The World's Most Advanced Massage Chairs®
72 Stard Road, Seabrook, NH 03874 | 603-910-5333
www.kyotamassagechairs.com
Version 1.2

KYOTA®


Quick Start Guide




Alternatively, scan the
QR code to watch a
remote tutorial video.

Kizuna M688
Massage Chair


KYOTA®




Auto Programs – Select from 12 pre-set auto programs. To select, simply tap the auto program you wish to run. To return to previous screen, tap the top left arrow.




Favorite – While running the program you wish to save, tap Favorite. Then tap Save in the slot you would like it stored. Return anytime to the Favorite screen and tap the corresponding Run button to recall and start the saved




Adjustments – Tap adjustments to change your chair's recline setting, turn on/off Meditation Music, Zero Gravity, Rocking, and add or reduce time.




Home Page – After turning on your chair, this is the first screen you will see. Use this screen to navigate all menu options. While running a program, tap the Home icon to return here.




Sound – Choose from 10 pre-set nature sounds. Tap to select the sound then set your volume level. To turn the sound off, de-select the activated sound.



Manual Settings – Use this screen to fully customize your own massage and find the perfect treatment for you. Manual Programs can also be saved as a Favorite after the program starts running, for easy recall.



Smart Message – Tap Smart Message and place your Index finger on the health sensor in the front of the Right armrest. The AI algorithm will combine your health scan with massage techniques to recommend a program specifically for you. When scanning is complete, view your scanned readings and tap to run the program.



Settings – Displays Sleep Mode, Bluetooth, Voice Control, and more.