## Installation and Assembly - Flat Panel Accessory for VCR/DVD Mount

Models: ACC931, ACC931-S

IMPORTANT! Read instruction sheet before you start installation and assembly.

Before you start make sure all parts listed are included with your product.

Parts  Description	Qty.	ACC931 Part #	ACC931-S Part #	AA III	BB	CC	DD
AA VCR/DVD bracket	1	201-1161	201-4161		378		
BB M5 x 8 mm phillips screw CC M5 x 20 mm phillips screw	4	570-0005 510-1208	570-0005 510-1208				
DD spacer	4	540-1057	540-1057				
Some parts may appear slightly different than illustrated.							

## **A WARNING**

• Do not overtighten! Overtightening may cause permanent damage to the screen. Torque to 26-35 in • lb (30-40 kg • cm).




Attach VCR/DVD bracket (**AA**) to back of adapter plate (sold separately) using the four screws included with adapter plate (sold separately) as shown below. Tighten screws using 4 mm security allen wrench included with adapter plate.


**Note**: Some parts may appear slightly different than illustrated.



Attach VCR/DVD mount (sold separately) to VCR/DVD bracket (**AA**) using four M5 x 8 mm philips screws (**BB**) as shown below.

**Note**: If using model SP850-UNL mount, Attach VCR/DVD mount to VCR/DVD bracket (**AA**) using four M5 x 20 mm philips screws (**CC**) and four spacers (**DD**) as shown below.





1 of 1

ISSUED: 07-03-07 SHEET #: 120-9037-2 08-27-10

