

SELF-AMPLIFIED SINGLE SPEAKER WIRING DIAGRAM

For OWI MODELS AMP1S51 and AMP1S61

Optional Accessories

INPUT/SOURCE

PROJECTOR,
LAPTOP, CD,
DVD or MP3
PLAYERS



To the LINE IN of
the next amplified
speaker (Optional)

To the next
amplified speaker
to a wall
outlet

12V AC (UL Listed)
Power Supply (Included)
(Model PS12VAC4A)

minimum 16 gauge wire

minimum 16 gauge wire
(30 feet maximum)

polarity
proof

to a wall
outlet

Speaker

Single Input
Amplifier PC Board
installed at the
back of Speaker



Volume Control



OWI
OWI Incorporated
WWW.OWI-INC.COM
310-515-1900
Tech Support
800.638.1694

**ONE (1)
SPEAKER
DETAILED
WIRING
DIAGRAM**

Note: Speaker wires A & B are factory installed with A connected to the positive and B connected to the negative of the Speaker.

minimum 16 gauge wire



Speaker
(Amplified
Speaker)

Note: A & B are
factory installed.



Touchboards

205 Westwood Ave, Long Branch, NJ 07740
Phone: 866-94 BOARDS (26273) / (732)-222-1511
Fax: (732)-222-7088 | E-mail: sales@touchboards.com

SINGLE SPEAKER HOOK UP SINGLE LINE DIAGRAM