# **DC-A11 Quick Start Guide**





# **Almportant**

- \* Please activate your warranty at <a href="https://www.MyLumens.com/reg">www.MyLumens.com/reg</a>
- \* To download the latest version of Quick Start Guide, multilingual user manual, software, or driver, etc., please visit Lumens<sup>™</sup> www.MyLumens.com/goto.htm
- \* To ensure successful installation, please be sure to follow each of the following steps.

## 1. Software Installation Guide

#### 1.1 System requirements

Windows XP	Windows Vista / Windows 7 / 8	MAC OS X 10.4 / 10.5 / 10.6 / 10.7 / 10.8
<ul> <li>Min CPU: P4 2.8 GHz</li> <li>Min Memory: 512MB</li> <li>Direct X 9 Compatible</li> <li>Min Resolution: 1024x768</li> <li>100MB Min Disc Space</li> <li>Windows XP SP2 and above</li> </ul>	Min CPU: P4 2.8 GHz     Min Memory: 1GB (32-bits)     /2GB(64-bits)     Direct X 9 Compatible     Min Resolution: 1024x768     100MB Min Disc Space	Min CPU: PowerPC G4 866MHz or Intel Pentium®1.83GHz Intel Core 2 Duo     Min Memory: 512MB     Min resolution 1024x768     24-bit color display monitor     1GB Min Disc Space     Min QuickTime 7.4.5

### → Windows XP / Vista / 7

#### 1. 2 Installing Ladibug™ / Podium View™

- 1.Download the **Ladibug**<sup>™</sup>/ **Podium View**<sup>™</sup> from Lumens<sup>™</sup> web site.
- 2.Click the **EXE** file after decompressing the downloaded file.
- 3. Please follow the instructions, then press [Next].
- 4. Press [Yes] to create a shortcut on your desktop.
- 5.Click [NO], then press [Finish] to cancel the restart. (Refer to Fig. 1) [NOTE: Please restart the computer only when the installation of Wireless LAN Utility is completed.]

#### 1.3 Installing Wireless LAN Utility

- 1.Download the Wireless LAN Utility from Lumens<sup>™</sup> web site.
- 2.Click the **EXE** file after decompressing the downloaded file.
- 3. Select Language.
- 4. Please follow the instructions, then press [Next].
- 5.Click the [Finish] button to restart your computer. (Refer to Fig. 2)






## → MAC


#### 1.4 Installing Ladibug™ / Podium View™

- 1.Download the **Ladibug**<sup>™</sup>/ **Podium View**<sup>™</sup> from Lumens<sup>™</sup> web site.
- 2.Click the **Ladibug**<sup>™</sup> / **Podium View**<sup>™</sup> icons for installation after decompressing the downloaded file.
- 3. Please follow the instructions, then press [Next].
- 4. Enter your ID and password then press the [OK].
- 5.Press the [Restart] icon to complete the installation.





#### 1.5 Installing Wireless LAN Utility


- 1.Download the Wireless LAN Utility from Lumens™ web site.
- Click the Wireless LAN Utility icons for installation after decompressing the downloaded file.
- 3.Press the Installer icon, open the installation wizard, and run the installation process by following the onscreen instructions.
- 4. Select the language then press [Continue].
- 5.Accept the software license agreement by pressing [I Agree]
- 6.Enter your ID and password then press [OK] .
- 7.Press the [Restart] to complete the installation.




## 2. Installation










# 3. Start Using



- ① Charge the unit for 3 hours before the first use.
- ② Switch power to [ON]. (Note: When the unit is fully charged, indicator (+)-) lights blue.)
- 3 To start connection, please refer to Section 4.1 Auto connection.
- Modify SSID before the first use. Please refer to 4.2 Change the SSID.
- 5 Double click [ Ladibug ] or [ Podium View ] to active software.
- 6 Point the cursor to the [Ladibug] or [Podium View] and the function menu pops up.
- Place an object to be displayed under the camera.
- 8 Press [ Preview ] to display a live image. Please make the following settings before the first use.
  - a. Windows security alert: Please press [Unblock].
  - b. Set the POWER Frequency according to the on-screen instructions.

A live image is displayed when the setting is finished.

- \* The black screen may occurs when you execute [Preview] of Ladibug or Podium because of the firewall. Please check the firewall setting and refer to DC-A11 user manual 6.2 Change the setting of firewall.
- Press [ AUTO TUNE ] to optimize the image.
- \* For more information on the operation of DC-A11 / DC120 / PC120, please refer to DC-A11 User Manual / DC120 User Manual / PC120 User Manual.



205 Westwood Ave, Long Branch, NJ 07740 Phone: 866-94 BOARDS (26273) / (732)-222-1511 Fax: (732)-222-7088 | E-mail: sales@touchboards.com





## 4. Start Wireless Network Connection


#### 4.1 Auto connection

- 1.Press the WPS button on your DC-A11. (Refer to Fig. 1)
- 2.Press and hold the WPS button on your dongle in 30 seconds. (Refer to Fig. 2)

Note: The WPS indicator on your DC-A11 flashes red first and turns to blue after being connected. ((Refer to Fig. 3)









#### ▶For PC users:


- 3. The connection is started when the screen like Fig. 4 displays. The connection will complete when the window closes.
- 4.Double click the icon of Wireless LAN Utility. (A screen indicating successful connection is as shown in Fig. 5)






#### ▶For MAC users

- 3. Connection starts once Fig.6 displays. Press the [OK] in Fig.7 to complete the connection.
- 4. See Fig.8 for successful connection indicator.





### 4.2 Change the SSID

- 1. Open the Internet Explorer browser, and enter [192.168.2.1] (default) in the address bar.
- 2, Enter the Login Name [Admin] and enter the default password [Admin] and click [Login].
- 3. Enter the [Basic] page and enter new [SSID] (Refer to Fig.9).
- 4. Click [Apply] to apply the changes then make a connection again according to the steps of 4.1 Auto connection.

