

Installing DTN 95°G3C, 97°IA5 & 103°AMC1 with Super Buddy™ meter



Connections: LNB connected to Super Buddy with coax cable.

Meter set-up:

Push the **SYST** System soft-key to select the following:

- REGION your geographic region
- SERVICE **Other Providers**
- SYSTEM **DTN** (meter defaults to Sngl Polar N. Am Ku LNB type)
- SWITCH TYPE defaults to **none**

To make selections, arrow up or down to the item to change and press **Enter**, then arrow up or down to the desired option and press **Enter**.

Press **EXIT** or **DONE** to return to Run Mode

Antenna Pointing

Install the mast plumb, preset the antenna vertical angle, mount to mast and grossly align azimuth.

Run Mode:

- Press the left/right arrow key to select the 95°, 97° or 103° satellite (orbital slot will be noted in upper left corner of display).
- Select the horizontal or vertical polarity (**HZ** or **VT**) with the upper right soft-key.
- Use the **LNB** soft-key to power the LNB.

After selecting the satellite, polarity and pressing the **LNB** soft-key to power the LNB:

- Align the antenna to obtain a strong signal level, LOCK and best signal quality value.
- Press the **ID** soft-key to verify the satellite. "ID VERIFIED" means you are pointed correctly.
- IF ID fails, press **SCAN** soft-key and Super Buddy will find the satellite you are aimed at.
- Use Up/Down arrows to scroll through transponders to check for proper level and quality.



Application Note
11/27/2006