

Installing **DIRECTV Triple Sat** with Super Buddy™ meter



Connections: LNB Cluster 101° 110° 119° connected to Super Buddy with single coax cable.

Meter set-up:

Push the **SYST** System soft-key to select the following:

- REGION your geographic region
- SERVICE **DIRECTV**
- SYSTEM **Triple Sat (Sat-C)**
- LNB MODEL defaults to **N/A**
- SWITCH TYPE defaults to **22 kHz**

To make selections, arrow up or down to the item to change and press **Enter**, then arrow up or down to the desired option and press **Enter**.

Press **EXIT** or **DONE** to return to Run Mode

Antenna Pointing

Preset the antenna and mast hardware per the directions of DIRECTV.

Run Mode:

Use the **LNB** soft-key to power the LNB and to toggle between satellites.

- LNB 1 = 101° (orbital slot will be noted in upper left corner of display)
- LNB 2 = 110° and 119° (Transponders 8,10,12 are from the 110° satellite, Transponders 22, 24, 26, 27, 28, 30, 31, 32 are from the 119° satellite)

NOTE: For multi-LNB systems we recommend you use the **LNB** button to select different satellites rather than the left/right arrows.

After pressing the **LNB** soft-key to power the LNB and select the satellite:

- Align the antenna to obtain a strong signal level and **LOCK**.
- Press the **ID** soft-key to verify the satellite. "ID VERIFIED" means you are pointed correctly.
- IF ID fails, press **SCAN** soft-key and Super Buddy will find the satellite you are aimed at.
- Use Up/Down arrows to scroll through transponders to check for proper level and quality.



Application Note
10/27/2006