

Installing Intelsat Americas 5 (Telstar 5) 97° with Super Buddy™ meter



Connections: LNB connected to Super Buddy with coax cable.

Meter set-up:

Push the **SYST** System soft-key to select the following:

- REGION your geographic region
- SERVICE **Generic Ku Band**
- SYSTEM Selection based on the style of your LNB (**Std N. Am Ku 10.75** or **Sngl Polar N. Am Ku** or **Universal**)
- LNB MODEL defaults to **N/A**
- SWITCH TYPE defaults to **none**

To make selections, arrow up or down to the item to change and press **Enter**, then arrow up or down to the desired option and press **Enter**.

Press **EXIT** or **DONE** to return to Run Mode

Antenna Pointing

Preset the antenna and mast hardware per the service provider's instructions.

Run Mode:

- Use the left/right arrow keys to select Intelsat Americas 5 Satellite. The 97° orbital slot will be displayed in the upper left corner of the Super Buddy's LCD screen.
- Use the LNB soft-key to power the LNB.

After selecting the satellite and pressing the **LNB** soft-key to power the LNB:

- Align the antenna to obtain a strong signal level and **LOCK**.
 - Press the **ID** soft-key to verify the satellite. "ID VERIFIED" means you are pointed correctly.
 - IF ID fails, press **SCAN** soft-key and Super Buddy will find the satellite you are aimed at.
- Use Up/Down arrows to scroll through transponders to check for proper level and quality.



Application Note

11/07/2006