

HT-2000P









ELECTRICAL M

Output:

Leakage Current

Pass/Fail Criteria: Ground Continuity: Leakage Current: Dielectric Breakdown: Test Time:

Voltage Ramp Time: Test Status: Duty Cycle: Meter Accuracy: **Discharge Time:** Test Adjustments: Included with tester:

ENVIRONMENTAL >>

Operating Temperature:: Relative Humidity Range: 15-40°C 0-90% non-condensing

Provided on rear panel.



GENERAL 🔰

Input Power Requirements: Weight: Dimensions:

114-127 volts. 50/60 Hz 10.5 lbs. 9.250 (W) x 4.250 (H) x 10.000 (L) in.



SAFETY M

Transformer Output: Visual Indication Of Voltage Output:

Failure Indication:

Ground Test:

<500 VA Provided by front panel meter, directly connected to high voltage output. Audible, provided by internal buzzer Visual, provided by red LED's on front panel Test automatically terminated on failure. Provided; 3 ohm pass/fail point. May be defeated for testing of products with two wire power supply cords. Provided; 5mA factory set pass/fail point, user adjustable.

Leakage Test: **Operation Instructions:**

The hue box that tests. And tests



205 Westwood Ave Long Branch, NJ 07740 1-877-742-TEST (8378) Fax: (732) 222-7088 salesteam@Tequipment.NET

Boulevard Suite 124 Del Mar, California 92014 USA 58] 481.8527 • www.compwest.com • sales@compwest.com



User adjustable 1-20 mA in 0.1 mA increments True arc detection using separate high frequency transformer. User adjustable 1-60 sec. in 1 second increments using LED display with HV output defeated. (See center picture above for test time display) User adjustable .5-5 sec. Progress Lights on Front Panel show test progress and results. 100% Immediate voltage discharge upon failure or end of test.

0-2000 Volts AC +0 -10% into NEMA 5-15R receptacle mounted on front panel

1-20 mA set using LED display with HV output defeated. (See picture on right above for

Pigtail and Receptacle adapters available for most configurations.

±2%: 500V to 2000V

leakage current display.)

3 ohm ± 5% * (defeatable)

Tamper-proof operation available by pulling knobs.

Calibration Certificate good for one year, User's Manual, return lead