
# NEW Accessory Heads

#### Introducing 4 new Fieldpiece heads

All heads connect to any meter with a mVDC range through Fieldpiece deluxe leads. With both contact and non-contact temperature, all your temperature measurement needs are covered.





#### ATH4

#### Dual Temperature Head

- -Two K-type ATB1 thermocouples with wrap tabs included
- -Auto-off
- -oF and oC
- -T1, T2, and T1-T2

### AUA2

#### Flame Rectifier Diode Test Head

- -Quick connect and mini-plug adapters
- -Microamps
- -Milliamps
- -No battery needed
- -Fuse protection





#### ATIR3

#### Infrared Temperature Head

- -Laser sight
- -Range: 0°F-752°F
- -Auto-off
- -oF and oC

## **AVH1**

#### Voltage Head

-Measure volts with the EHDL1 and DL2.

-No battery needed



www.Tequipment.net 205 Westwood Avenue, Long Branch, NJ 07740 Phone: 1-877-742-TEST (8378) Fax: (732)-222-7088 Email: salesteam@tequipment.NET