Manual Supplement

Manual Title:1750 OperatorsPrint Date:October 2006Revision/Date:3, 11/10

Supplement Issue:1Issue Date:2/11Page Count:1

This supplement contains information necessary to ensure the accuracy of the above manual. This manual is distributed as an electronic manual on the following CD-ROM:

CD Title: CD Rev. & Date: CD PN: 1750 10, 12/2009 2774701





Change #1

On page 5, replace the text above *Features* with:

You can also order these optional accessories. For more information about accessories, see *Contacting Fluke* earlier in this manual. An updated list is always available on <u>www.fluke.com</u>.

- CS1750/1760 Case Polyester, for Fluke 1750 & 1760
- Fluke-1750/Case Transit Case, Molded, Flk-1750 and 1760
- 4006 RPM, Security CBL, Steel, 6 ft. Looped Lockable
- 4003 RPM, Shipping Caddy with Wheels
- 4005 RPM, Shipping Container, Reusable
- Replacement Voltage Lead Set
- Clamp-on Current Transformers (i5s-PR 5 Amp, Clamp with 10 ft. Cable, i40s-PR 40 Amp, Clamp with 10 ft. Cable), Flex CT 24 in, 3140R Current Clamp, 400 Amp
- Flexible Current Transformers 3210-PR-TF 1000 Amp, Flex CT 24 IN, 3310-PR-TF 5000 Amp, Flex CT 24 in., 3312-PR-TF 5000 Amp, Flex CT 48 in.
- Interface and Extension Cables 3570 CT Cable
- Replacement/Additional Memory card: Fluke-1750/MC2GB 1750 2GB Secure Digital Memory Card



205 Westwood Ave Long Branch, NJ 07740 1-877-742-TEST (8378) Fax: (732) 222-7088 salesteam@Tequipment.NET