## **Manual Supplement**

Title: 922 Users Supplement Issue: 1
Part Number: 2683880 Issue Date: 11/06

Print Date: Nov. 2006 Page Count: 2

Revision/Date:

This supplement contains information necessary to ensure the accuracy of the above Instruction Sheet.



205 Westwood Ave Long Branch, NJ 07740 1-877-742-TEST (8378) Fax: (732) 222-7088 salesteam@Teguipment.NET



## Change #1

On page 6, Table 2, replace item 5 with the following:

5 Calculates average of stored values.

On page 8, Table 3, replace item11 with the following:

11) Min Max, and Hold indicators

On page 12, replace the first sentence in step 3 with the following:

- 3. Press AVERAGE, PRESSURE, VELOCITY or FLOW VOLUME to exit calculate mode.
- On page 19, add step 4 prior to *Recall*:
  - 4. To exit (CLEAR) or (CLEAR ALL) without deleting samples, press PRESSURE, VELOCITY or VOLUME before pressing WEE.

## Change #2, 38872

On page 22, under **Specifications**, add the following footnote:

Use of Zero function is required to achieve these specifications.

