

# Driver Update Required

InterpretAir Client uses some features of the Wi-Fi adapter drivers that are only available in certain driver releases. This installation includes updated drivers for supported Wi-Fi adapters. These drivers are copied to *C:\Program Files\Fluke Networks\Drivers*, where you can install them, if needed.

## Atheros 802.11 a/b/g Adapters

InterpretAir Wireless Utility version 3.1.3.10, includes driver version: 3.3.0.170.  
**To install**, run the setup.exe located in the Atheros folder.

Supported Atheros adapters include for example the following Wi-Fi adapters. Other Atheros Wi-Fi cards with AR5001A, AR5001X, AR5001X+, AR5002G, AR5002X, AR5004G, and AR5004X chipset might also work, but those have not been tested by Fluke Networks.

- Avaya 802.11ab ComboCard
- Cisco Aironet 802.11a/b/g Wireless Adapter (CB21AG)  
**NOTE: Only install the driver, use the Cisco supplicant**
- D-Link AirPlusXtremeG DWL-G520 Adapter
- D-Link AirPlusXtremeG DWL-G650 Wireless Cardbus Adapter
- D-Link AirXpert DWL-AG520 Wireless PCI Adapter
- D-Link AirXpert DWL-AG650 Wireless Cardbus Adapter
- Fluke Networks EtherScope WLAN Card
- Lancom AirLancer MC-54ab
- Lancom AirLancer MC-54ag
- Lancom AirLancer MC-54g
- Lancom AirLancer PCI-54a
- Lancom AirLancer PCI-54ag
- Lancom AirLancer PCI-54g
- Linksys Dual-Band Wireless A+G Notebook Adapter (WPC55AG)
- NETGEAR WAB501 802.11a/b Wireless Adapter
- NETGEAR WAG511 802.11a/b/g Dual Band Wireless PC Card
- Nortel Networks WLAN - Mobile Adapter 2201
- ORiNOCO 802.11a/b ComboCard Gold (8460)
- ORiNOCO 802.11a/b ComboCard Silver (8461)
- ORiNOCO 802.11a/b/g ComboCard Gold (8480)
- ORiNOCO 802.11a/b/g ComboCard Silver (8481)
- ORiNOCO 802.11a/b/g PCI Adapter (8482)
- ORiNOCO 802.11b/g PC Card Gold (8470)
- ORiNOCO 802.11b/g PC Card Silver (8471)
- SMC2336W-AG Universal Wireless Cardbus Adapter

## Intel Centrino

The latest driver version is available at the [Intel WLAN Product Downloads](http://support.intel.com/support/wireless/wlan/)

(<http://support.intel.com/support/wireless/wlan/>).

**NOTE:** Use version 9.0.2 or later. Please carefully choose the correct Centrino model number.

**To install**, run the executable after downloading it from the website.

Supported Intel Centrino adapters include

- 2100B
- 2200BG
- 2915ABG

## Cisco Adapters 350 and CB-20A

Client Adapter Installation Wizard v1.5. Includes NDIS Driver 8.5.26/3.8.26.

**NOTE for CISCO CB-21ABG USERS: Do NOT use these drivers - use the Atheros drivers above for Cisco CB-21ABG**

**To install**, please run the WinClient-802.11a-b-g-Ins-Wizard-v1204.exe located in the Cisco folder.

Supported Cisco adapters include

- Cisco Aironet 350 Wireless LAN Client Adapter
- Cisco Aironet 5 GHz 54 Mbps Wireless LAN Client Adapter (CB20A)

## Agere 802.11b Adapters

Driver version: 7.82.0.542 (sr02-02.3)

**To install**, please update the driver located in the sr02-02.3 folder using the Windows Device Manager. If necessary, install also the Agere Client Manager located in the Cl\_Mgr folder.

Adapters with Agere chipset include for example

- Avaya Wireless World Card
- Buffalo AirStation WLI-PCM-L11GP
- Enterasys RoamAbout
- HP H220W
- IBM High Rate Wireless LAN PC Card
- ORiNOCO (Classic) Silver&Gold
- ORiNOCO USB Client



**Tequipment**  
**.NET**

205 Westwood Ave  
Long Branch, NJ 07740  
1-877-742-TEST (8378)  
Fax: (732) 222-7088  
salesteam@Tequipment.NET