


9772-90 Replacing the Pin

The model 9772-90 pin is a replacement part for the model 9772 PIN TYPE LEAD. Perform the following steps to replace the pin.




1. Turn off the power of the device and remove the 9772.
2. Pull out the pin tip to be replaced, using pliers or a similar tool.

Model 9772
PIN TYPE LEAD



3. Replace the 9772-90 pin tip by inserting a new pin into the socket and pressing against a hard board or other surface to fix the pin firmly in place.

Model 9772-90's pin



4. Check the performance. Measure an object with a known resistance. Make sure that the measured resistance is correct before using the pin type lead.

Specifications

Operating temperature and humidity	0°C to 40°C (32°F to 104°F), 80%RH or less (no condensation)
Storage temperature and humidity	-10°C to 50°C (14°C to 122°C), 80%RH or less (no condensation)
Operating Environment	Altitude up to 2000 m (6562 feet), Indoors
Size&Weight	Approx. 19 mm (0.75")/ Approx. 0.15 g (0.005 oz.)
Accessories	Instruction manual

