

# Quick Start Card

## HD81-LV Home Theater Solution



- 1** Plug in the power cords from the projector and scaler to the outlet.



- 2** Connect the HDMI cable from projector to the scaler.



- 3** Connect the RS-232 cable from projector to the scaler.



- 4** Connect short HDMI cable if AV receiver is not being used through the scaler



- 5** Connect the external IR receiver



- 6** Remove the lens cap.



- 7** Push the power button on the scaler.



- 8** Manually adjust the zoom and focus.



- 9** Insert the batteries into the remote.




# Quick Start Card

## HD81-LV Home Theater Solution



### Connection Options



### Accessory Options

