



565C1 Hotwire Air Velocity Meter

APPLICATIONS

- Air flow measurements in heating, ventilation and air conditioning systems
- Where low and high feet per minute readings are critical - you must use a hot wire below 80 feet per minute.



Comes hardwired with protective boot (A604)

Turn over for technical information and accessory part numbers.

The Value Leader™

Features

- Air flow 0.2 to 20 m/s (Also reads km/s, ft/min, knots/h, miles/h)
- Temperature -5° to 175° F (-20° to 80°C)
- Data record function for maximum and minimum temperature and air velocity reading
- Download to a computer using the RS-232 port and optional A500 cable. (The 565 uses Microsoft® Hyper Terminal to download and display air velocity and temperature on your PC.)
- 39" cable length, hard wired, telescoping tip expands from 10" to 37" (cable length decreases to 12" at full extension)
- Data Hold
- Auto Power Off
- Protective Boot Included



TECHNICAL SPECIFICATIONS AND ACCESSORIES

- Digital Multimeters
- Clamp Meters
- Hand-held Oscilloscopes
- Refrigerant & Combustible Gas Leak Detectors
- Temperature Testers
- BNC Coax Cable Connectors
- Test Leads
- Accessories

Test Products International, Inc.
 Headquarters:
 9615 SW Allen Blvd.
 Beaverton, OR 97005
 USA

Test Products International, Ltd.
 342 Bronte St. South
 Unit 9
 Milton, Ontario L9T 5B7
 Canada

Test Products International UK Ltd.
 Longley House, East Park
 Crawley, West Sussex
 RH10 6AP England

565 Hotwire Air Velocity Meter

SPECIFICATIONS

Display	Dual digits LCD with function annunciation
Measurement	m/s, km/s, ft/min, knots, mile/h, °C, °F
Measurement Range and Accuracy:	
Air Flow (Hot) Sensor	0.2 ~ 20 m/s (±5% of reading ±3 digits)
Temperature	-5°F ~ 175°F (±1% of reading ±1.0°F ±3 digit) -20°C ~ 80°C (±1% of reading ±0.5°C ±3 digit) <i>*Sensor: Precision glass bead thermistor</i>
Operating Temperature	0 ~ 50°C (32°F ~ 122°F)
Operating Humidity	Less than 80% R/H
Powering	1.5V AAA x 6ea
Optional Accessories	A500 RS-232 cable A910 soft shoulder strap carrying case

Distributed By:



**205 Westwood Ave
 Long Branch, NJ 07740
 1-877-742-TEST (8378)
 Fax: (732) 222-7088
 salesteam@Tequipment.NET**




**205 Westwood Ave
 Long Branch, NJ 07740
 1-877-742-TEST (8378)
 Fax: (732) 222-7088
 salesteam@Tequipment.NET**