


Wahl Heat Spy® Imager Thermal Imaging Camera

How Field of View Works

10 DEGREE FIELD OF VIEW




Distance from Imager (ft)	Scene size	Pixel (in)
4.9	10.3x10.3 in	.6x.6
6.6	13.8x13.8 in	.9x.9
16.5	34.4x34.4	2.2x2.2
33	5.74x5.74	4.3x4.3

Wahl Heat Spy® Imager Thermal Imaging Camera

How Field of View Works

20 DEGREE FIELD OF VIEW

IMAGER




Distance from Imager (ft)	Scene size	Pixel (in)
3.3	13.8x13.8 (in)	.9x.9
4.9	20.7x20.7 (in)	1.3x1.3
6.6	27.6x27.6 (in)	1.7x1.7
16.5	5.7x5.7 (ft)	4.3x4.3
33	11.5x11.5 (ft)	8.7x8.7

Wahl Heat Spy[®] Imager Thermal Imaging Camera

How Field of View Works

FIELD OF VIEW



IMAGER




Wahl Heat Spy[®] Imager Thermal Imaging Camera

How Field of View Works


PIXEL TEMPERATURE MEASUREMENT



CORRECT TEMPERATURE MEASUREMENT



INCORRECT TEMPERATURE MEASUREMENT



INCORRECT TEMPERATURE MEASUREMENT