

The default temperature read-out of the Process Multimeter is in Celsius (°C).

To change it to Fahrenheit (°F), it is necessary to proceed as follows:

Changing the temperature unit setting to Fahrenheit

SEE ALSO

For more information on operation, see User's Manual (IM CA450-EN).

4.3.3 Measuring Using Sensors (SENSOR)

4.6.2 SENSOR Mode Input, Display, and Unit Settings

Model CA450

Displaying " °C " only is configured at factory before shipment. Carry out the following setting procedure to display " °F ". While pressing the SELECT, RANGE and HOLD keys simultaneously, turn the function switch to any position.

In the unit area of the main display in SENSOR mode of the setup function, °F will appear after °C. You will be able to select °F.

6.3 Detailed Command Descriptions

"4: °F" will be added as another m (unit) parameter value for the SU command (which sets or queries the unit for SENSOR mode).



205 Westwood Ave
Long Branch, NJ 07740
1-877-742-TEST (8378)
Fax: (732) 222-7088
salesteam@Equipment.NET