


## **MX-1 New Baseplate Installation Guide**



**WARNING:** Before you begin installing the new MX-1 baseplate, make sure that your MX-1 unit is not plugged into anything else, including the optional ELMO Connect Box.






Using a screwdriver, carefully remove the 2 screws from the bottom of the baseplate. The baseplate is magnetized and will not come off until manually removed.



Take off the baseplate and screws. **Do not** throw away your baseplate – you may need the serial number for later reference.



Place the new MX-1 baseplate on the bottom of the unit, making sure that it is properly aligned with the unit.



Replace the 2 screws and screw them back into the bottom of the new baseplate to finish installation.





## **MX-1 New Baseplate Installation Guide**

To use the MX-1 Writing Board, slide the baseplate of the MX-1 unit into one of the two slots located on the bottom of the Writing Board. This will keep the camera in place as you write



The MX-1 Writing Board is now ready to be used! Simply connect the MX-1 to the input source of your choice.



When you are finished using the MX-1 and Writing Board, the MX-1 unit can be folded shut while it is still attached to the Writing Board.





205 Westwood Ave, Long Branch, NJ 07740 Phone: 866-94 BOARDS (26273) / (732)-222-1511 Fax: (732)-222-7088 | E-mail: sales@touchboards.com