



LAP15EBOX

15 Outlet Electrical Unit


Assembly Instructions


CAUTION: This LAP15-E electrical unit is designed for a standard 15 amp service and is intended to be used for charging 15 laptop computers. Any other use may overload the circuit and cause the circuit breaker to trip. The circuit breaker is built into the on/off switch located on the right side of the power tap above the power cord exit. To reset the circuit breaker, simply turn the power tap off and then on, again.

CAUTION: RISK OF ELECTRICAL SHOCK. DO NOT PLUG INTO ANOTHER RELOCATABLE POWER TAP.

PARTS LIST


Qty	Part#	Description
1	LAP15-E	15 Outlet Electrical Unit
4	030-0006	1/4-20 Wing Nuts





STEP 3

Prior to attaching E-unit, lower upper back panel door to expose inside of cart. The E-unit is to be located in the upper half of the cart. Power outlets must face the back of the cart. Move the E-unit into the cart and slide it onto the weld nuts on both sides of upper half of your cart. Secure the E-unit in place with four wing nuts. Attach the wing nuts onto the weld nuts as shown. **NOTE:** The E-unit **MUST ONLY** be installed using the hardware provided. Pull the power cord through the large grommeted hole in the lower back panel as shown.



1/4-20 Wing Nut
030-0006

Bretford
11000 Seymour Avenue
Franklin Park, IL 60131
TEL: 847.678.2545
800.521.9614
FAX: 847.678.0852
800.343.1779

www.bretford.com

Part#031-2875
Rev. 08.29.05 CH