



Disc Launcher



The **Disc Launcher unit** (only in SCROV-50 Deluxe Snap Snap Rover) contains a complex electronic circuit to control when the loading and launching motors start up and shut down, and to flash the lights in the “eyes”. Its schematic is shown at left.

Its Snap Circuits connections are like this:



Disc Launcher:

- (+) - power from batteries
- (-) - power return to batteries
- CONT - control input (active low)
- EXT - external device control (active low)