



H670


H671, H672, H673, H674




スピーカー/Speaker
リモコン受光部/Remote receiver






ランプカバー/Lamp cover
制御パネル/Control panel
幅補正スライダー/Width correction slider
フォーカスリング/Focus Ring
A/Vミュートボタン/ Button A/V MUTE
323 [12.72"]
344 [13.54"]
113.9 [4.48"]
Lens Center
A4



天吊り用ネジ 5-4M
取付穴深さ9mm/
5-4M for ceiling mount
depth 9mm
リアフット/Rear Foot
エアフィルターカバー/Air filter cover
230.5 [9.07"]
185.9 [7.32"]
156 [6.14"]
128 [5.04"]
117 [4.61"]
68.883 [2.7108"]
27.5 [1.08"]
8 [0.31"]
127 [5.00"]
137 [5.39"]
55.9 [2.2"]
242 [9.53"]
12 [0.47"]
13.62"
フロントフット/Front Foot
A4



リモコン受光部/Remote receiver
132 [5.20"]
53.94 [2.12"]
Lens Center
インタラクティブ受光部/interactive function receiver
2 [0.08"]
A4



インタラクティブ受光部/No interactive function receiver

<Note>
Unit of Dimension
Upper:mm
Lower:inch