

233








True-rms Remote Display Digital Multimeter





Quick Reference Guide

Warning






To prevent possible electrical shock, fire, or personal injury, read the "233 Safety Information" before you use this Product.

Go to www.fluke.com to register your product and find more information.






Remote Display



ToolPak



Ignore rF Err