


Head and Ram Illustration and Parts List—ETS12L



Key	Part No.	Description	Qty
	52033626	Head assembly (includes 1–7)	
	52033628	Cutter blade kit (includes 1–4).....	1
1		Fixed blade.....	1
2		Movable blade.....	1
3		Roll pin	1
4		Socket head cap screw.....	1
5	50019295	Hex head cap screw, m3x4.....	1

Key	Part No.	Description	Qty
6	50019236	Compression spring	1
7		Cutter head	1
8*		O-ring (included in 50047957).....	1
9*		Piston backup ring (included in 50047957)	1
10	50019082	Bushing	1
11	52024564	Pinch hazard decal.....	1