






NOT ALL PARTS OF THE PJSP ASSEMBLY KIT ARE SHOWN, ONLY THE PARTS USED IN THE FLUSH INSTALLATION OF THE PANEL. FOLLOW INSTALLATION INSTRUCTIONS INCLUDED IN THE KIT FOR THE OPTIONAL PANEL MOUNTING

DUAL NUT NOT INCLUDED IN PJSP ASSEMBLY PACKAGE

ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	70-60425	ACORN CAP NUT EXTRA SHORT	4
2	70-60426	#6 LOCK WASHER	4
3	70-60428316	#6-32X.375 COMBO PAN HEAD MACHINE SCREW	4
4	70-60431316	#6 FLAT WASHER	4
5	70-60511316	RIVET, BLIND, #43 (.125-.188 GRIP RANGE)	2
6	70-60861	SPRING LATCH	1
7	70-632316	PAN HEAD EXTERNAL SEMS SCREW	4
8	70-60832-1	Swing Panel, 16x14, aluminum	1
9	70-632DUALNUT	#6-32 DUAL NUT	2
10	70-60859	PANEL STOP	2
11	70-60804a	PANEL HINGE-5"-FLANGE A	2
12	70-60804b	PANEL HINGE-5"-FLANGE B	2
13	.	ENCLOSURE	1
14	70-432716316REV	#6-32 x .4375 316SS W GRVD SILICONE ORING PN VEIT	4



PART No. PJSP1614

for more information visit
www.hammfg.com
Data subject to change without notice
Drawing Not to Scale