
























# High-accuracy measurement

ME15W	Directly wired	External power supply + connection cord			Conversion cable	
CT6862-05			 <p><b>CT9555, CT9556</b> Connects one sensor</p> <p><b>CT9557*</b> Connects four sensors.</p> <p><b>L9217</b> Isolated BNC</p> <p><b>9165</b> metallic BNC</p> <p>Connects CT9555, CT9556 or CT6557 and instrument.</p>			 <p><b>CT9901</b> Converts ME15W terminal to PL23 terminal</p>
CT6872						
CT6872-01						
CT6863-05						
CT6873						
CT6873-01						
CT6875A	<b>ME15W</b>	<b>BNC</b>	<b>BNC</b>	<b>BNC</b>	<b>PL23</b>	
CT6875A-1						
CT6904A	<b>PW8001</b>	<b>PW3335-03</b>	<b>U8975</b>	<b>MR8870</b>	<b>8971+9318</b>	
CT6904A-1	<b>ME15W</b>	<b>BNC</b>	<b>BNC</b>	<b>BNC</b>		
CT6904A-2						
CT6904A-3	<b>PW6001</b>	<b>PW3335-04</b>	<b>U8976</b>	<b>MR8880</b>		
CT6876A	<b>ME15W</b>	<b>BNC</b>	<b>BNC</b>	<b>BNC</b>		
CT6876A-1						
CT6877A	<b>PW3390</b>	<b>PW3336</b>	<b>U8978</b>	<b>MR8875 + MR8901</b>		
CT6877A-1	<b>ME15W</b>	<b>BNC</b>	<b>BNC</b>			
9272-05						
CT6841-05	<b>U8977</b>	<b>PW3337</b>	<b>8966</b>			
CT6843-05			<b>BNC</b>			
CT6844-05						
CT6845-05			<b>8968</b>			
CT6846-05			<b>BNC</b>			
PW9100A-3						
PW9100A-4	<b>CT9902 (ME15W-ME15W)</b> The CT9902 can be used to extend a current sensor's cable by 5 m. Up two of these cables can be used for a maximum extension of 10 m. *When using the CT9902, an addition must be made to accuracy. For details, see the sensor's user manual.		<b>8972</b>			

\*The CT9557 can output four channels of input as an added waveform.

		
	<b>Sensor input</b>	<b>1 2 3</b>
<b>1</b>	Total RMS output (BNC)	CONNECTION CABLE <b>L9217, 9165</b> BNC-BNC
<b>2</b>	Total waveform output (BNC)	CONNECTION CABLE <b>L9217, 9165</b> BNC-BNC
<b>3</b>	Total waveform output (ME15W)	CONNECTION CABLE <b>CT9904</b> ME15W-ME15W

We accept special orders for extending sensor cables. For inquiries, please contact Hioki for more information.