

PC MODULE

How to remove the PC Module (In six easy steps)

- 1) Power down the Mondopad through the Windows Start Menu.
- 2) Unplug the AC Power from the Mondopad Housing Panel.







SECURITY TOOL



- 3) Rotate the two Antenna Connectors counter clockwise to disconnect them.
- 4) Using the Security Allen Wrench provided, remove the two Security Screws.



5) Use the handle to pull out the *PC Module* .



HANDLE

6) After reinstalling the *PC Module*, reconnect the *AC Power*.