



SADS, SAPS, SAMS, SHTS, SATS, SDSS, SDRS, SALS, SDNS, SNHS, STES, SJTS, SSFS, SWSBT

Tool Holders for Stands

This manual corresponds to the following references*:

0015450 SADS for ADS & HDS 0016268 SAMS for AMS 0028036 SATS for ATS 0016273 SDRS for DRS 0016274 SDNS for DNS 0016227 STES for TES 0018634 SSFS for SFS 0016267 SAPS for APS
0016269 SHTS for HTS & HDTS
0016272 SDSS for DSS
0016275 SALS for ALS
0028410 SNHS for NHS
0016276 SJTS for JTS
0028411 SWSBT for WSBT

Packing List

The following items are included:

Manual 1 unit Ref. 0028444

Replacement




Before carrying out maintenance, always unplug the tool. Allow the equipment to cool down. Be sure that the power supply is disconnected before changing any spare part.



Changing the Tool Holder


Remove the locking knob (1).

Separate the tool holder from the stand and remove the holder screw (2).



Carefully move the tool holder sidewards until the cable* comes out (3).

Place the new tool holder following the disassembling steps conversely.



^{*}The following references come without cabel connection:

⁻ Ref. 0018634 SSFS for SFS

⁻ Ref. 0028411 SWSBT for WSBT

Specifications

SADS / SAPS / SAMS / SHTS / SATS / SDSS / SDRS / SALS / SDNS / SNHS / STES / SJTS / SSFS / SWSBT Tool Holders for Stands

Ref.: see page 2

- Package Dimensions: 111 x 81 x 41 mm $(L \times W \times H)$ 4.37 x 3.19 x 1.61 in

Complies with CE standards.



Warranty

JBC's 2 year warranty covers this equipment against all manufacturing defects. including the replacement of defective parts and labour.

Warranty does not cover product wear or misuse.

In order for the warranty to be valid, equipment must be returned, postage paid, to the dealer where it was purchased.



This product should not be thrown in the garbage. In accordance with the European directive 2012/19/EU, electronic

equipment at the end of its life must be collected and returned to an authorized recycling facility.





www.jbctools.com