



Solder Feed Handle

Ref. SF280-A

Packing List

The following items should be included:

 Solder Feed Handle
 1 unit
 Manual
 1 unit

 Ref. SF280-A
 Ref. 0019089





Connection





Replacing the guide tube

For this operation, disconnect the tool from the control unit.

1. Open the guide clamp, take off the guide tube and insert the new one.



2. You can easily adjust the length of the tube by opening the guide clamp.



Accesories

Solder Feed Handle Stand

Ref. SF-SD



It prevents the SF280-A Solder Feed Handle from rolling away while working.

Guide Set

Ref. GSF05 - wire Ø 0.5 mm Ref. GSF08 - wire Ø 0,8 mm without Ref. GSF10 - wire Ø 1 mm V-Cut Ref. GSF15 - wire Ø 1,5 mm

Ref. GSF08V - wire Ø 0,8 mm Ref. GSF10V - wire Ø 1 mm

with V-Cut Ref. GSF15V - wire Ø 1,5 mm



Specifications

- Weight: 60 gr (0.01 lb)

- Solder wire diameter with V-Cut: Ø 0,08 - 1 - 1,5 mm (0.003 - 0.04 - 0.06 in)

- Solder wire diameter without V-Cut: Ø 0,05 - 0,08 - 1 - 1,5 mm (0.002 - 0.003 - 0.04 - 0.06 in)

Complies with CE standards ESD protected



Warranty

JBC's 2 year warranty covers this equipment against all manufacturing defects, including the replacement of defective parts and labour. Warranty does not cover product wear or misuse. In order for the warranty to be valid, equipment must be returned, postage paid, to the dealer where it was purchased.



This product should not be thrown in the garbage.

In accordance with the European directive 2002/96/EC, electronic equipment at the end of their life must be collected and returned to an authorized recycling facility.





Manual in other languages available on our website