



PTX-FLA Instruction Manual

Universal Flashlight Kit For PTX

(Batteries Included)



Installation Instructions:

- 1. Loosen housing nut
- 2. Slide unit on to the PTX tool
- 3. Tighten housing nut

Note: The flashlight uses a AA battery, which is easily replaced by unscrewing the end cap.

