





### Item No.:X2N


Installation guide







205 Westwood Ave, Long Branch, NJ 07740 Phone: 866-94 BOARDS (26273) / (732)-222-1511 Fax: (732)-222-7088 | E-mail: sales@touchboards.com








STEP4













# STEP2







## CAUTION

This product contains small items that could be a choking hazard if swallowed. Keep these items away from young children.

- Pls read the intruction manual carefully before installation and follow the procedure step by step.
- Make sure the security lock is locked to prevent from accidentally dropping of the tablet.
- Make sure the connecting screw is installed correctly.

Make sure the tablet is less than 2.2lbs before using, any accidental dropping for tablet over 2.2lbs is not responsible of vendor

Note: this product is intended for indoor use only. Use of this product outdoors could lead to product failure or personal injury.

#### ZOXOU INC.

ADDRESS: 47618 Kato Road,Fremont,CA,94538 United States. TEL:1-855-421-2808

Facebook:Loctek Twitter:LoctekOfficial

### LOCTEK VISUAL TECHNOLOGY CORP ( MANUFACTORY )

ADDRESS: No.588 Qihang South Road, Binhai Industrial Zone, Yinzhou District, Ningbo China.