


Mobile Flat Panel TV Stand & Mount Instructions

Touchboards


205 Westwood Ave, Long Branch, NJ 07740
Phone: 866-94 BOARDS (26273) / (732)-222-1511
Fax: (732)-222-7088 | E-mail: sales@touchboards.com

Part List:

- | | |
|-----------------------------|-----------------------------|
| 1 x Vertical Upper Bracket | 4 x 3/8 x .75" Bolts |
| 1 x Leg Frame | 14 x 3/8 x 2" Bolts |
| 2 x Lower Support Bracket | 16 x 3/8 Nuts |
| 2 x Shelf Bracket | 4 x .5" Self Tapping Screws |
| 1 x Shelf | |
| 1 x Caster Set (2 w/ Brake) | |




- 1** Attach the casters to the leg frame.




- 2** Place the Leg Frame plate onto the leg frame. Attach the vertical frame member to the leg frame with 2 x 3/8 x 2" Bolts.

- 3** Install the Lower Support Brackets with 4 x 3/8 x 2" Bolts and 4 x 3/8 Nuts to the vertical support member, and 4 x 3/8 x .75" and 4 x 3/8 Nuts to the leg frame.




4

Attach the Shelf to the shelf brackets with 4 x Self Tapping Screws
Attach the Shelf Assembly to the Vertical Support Member with 4 x 3/8 x 2" Bolts and 4 x 3/8 Nuts.



5

Attach the WFST BRACKET to the assembled unit with 4 x 3/8 x 2" bolts and 4 x 3/8 Nuts. Follow the instructions included in the WFST Bracket box to mount the TV.



Touchboards

205 Westwood Ave, Long Branch, NJ 07740
Phone: 866-94 BOARDS (26273) / (732)-222-1511
Fax: (732)-222-7088 | E-mail: sales@touchboards.com