
## Systems Configurations BVX-100 Series Fume Extraction




BVX-101 On bench with exhaust Arm

#### Other possible configurations:

- On bench with plenum (**BVX-101S**)
- On shelf with Arm & inverted adapter (BVX-IADT)
- With under bench bracket (**BVX-BCK**)
- On the floor with flexible Arm kit (**BVX-ARM-K1**)

#### **BVX-200 Series Fume Extraction**



Other possible configurations:

- BVX-200 with flexible hoses (BVX-Arm-K1) & BVX Arms. The flexible hoses offer greater spacing between arms.) For longer hoses you can order individual components (*www.Metcal.com*)
- **BVX-200** with flexible hoses & Omniflex Arms

FA1124



FA1122






FA1126

# **Systems Configurations**

### MFX-2200 Series Fume Extraction

#### Pre/HEPA/Gas with Exhaust Arms

#### MFX-2200C-A or MFX-2200C-D



#### Other possible configurations:

- Up to 4 users with Omniflex Arm EA1122 rectangular nozzle & EA1126 large hood per unit
- Up to 8 users with BVX-ARM per unit (BVX-ARM-K2: BVX Arm ESD with nozzle, mounting plate and C-Clamps)

All Arms are supplied with mounting bracket and two C-Clamps.

## **BTX-208 Tip Extraction Duct Layout**

The **BTX-208** can provide fume extraction for up to 8 stations. Select a duct connection kit based on the number of stations, the layout and the length of ducting.


#### **Connection Kits:**

- **BTX-CK2-25** For 2-4 stations w/2.5m (8') long hose
- **BTX-CK4-50** For 4-8 stations w/5m (16') long hose
- **BTX-CK4-75** For 4-8 stations w/7.5m (25') long hose

Download our Guide to Safely Manage Solder Fumes In the Workplace and our Fume Extraction Planning Guide at: www.OKInternational.com/Metcal/



www.Metcal.com




## Fume Extraction Product Guide

Single & Multi Users



# Which System Should You Buy?



**Universal Iron Adapter Clip - BTX-UC01**