



The MimioTeach™ interactive whiteboard easily turns any dry erase whiteboard into an interactive system.



Depressing tip, while holding down Button A, creates Right-Click.

Dock the stylus on the side of the MimioTeach bar for recharging when not in use. Status light will turn solid green during charging.*

*An amber light on the stylus indicates that it must be recharged immediately.



Status Light

Off: Not receiving power; USB/power cable is not connected, or MimioTeach is turned off.

Solid Green: MimioTeach is connected and receiving power; MimioStudio™ software is running.

Flashing Green: MimioTeach is connected and receiving power; MimioStudio software is not running.

Solid Amber: MimioTeach is connected and receiving power; MimioTeach is searching for connection to the MimioHub™ receiver.



205 Westwood Ave, Long Branch, NJ 07740
Phone: 866-94 BOARDS (26273) / (732)-222-1511
Fax: (732)-222-7088 | E-mail: sales@touchboards.com