

CHAIR GUARD INSTRUCTIONS

For All Model #s: CG28, CG32, CG37, CG44, CG54, CG72, CG81, CG96

Materials Included:

- 1- 1 inch round tube Metal Chair Guard
- 6- 1 inch pan-head Phillips screws

Recommended Tools: power tool with Phillips head bit

Assembly Instructions:

- Lay Chair Guard flat on surface edge of stage (back or side) with tabs facing inward on the surface of the stage.
- The back of the Chair Guard should be aligned with the back of the stage back.
- The Chair Guard should be centered on the stage assuring protection for the entire length or width of the stage.
- Fasten screws with Phillips head shaped drill bit until the tab is laying flat and flush with the surface of the stage. To ensure safety, use all 6 screws provided with the Chair Guards, 2 screws for each of the 3 tabs on the Chair Guard.

Chair Guard flush with stage back or sides of stage.

Chair Guard screwed with 2 screws per tab (2 screws each for 3 tabs, 6 screws total). Tabs should lay flat on stage.

