Range: -58 to 302°F (-50 to 150°C)
Resolution 0.1° from –20.0 to 100°C
Accuracy: ±1°C from –20 to 200°C

SPECIFICATIONS

Slide the power "ON/OFF" switch to the "ON" position. 2. Slide the "C/F" switch to select the

Press the "HOLD" button again to

OPERATION

desired reading.

freeze the display.

3. Press "HOLD" button once to

resume measurement.

battery life. Keep plastic housing and plastic handle away from heat source. Do not place inside oven or

cable in liquid.

1. Use a coin to open the battery cover on back of unit.

2. Replace with catalog number 1039.

BATTERY REPLACEMENT

expose to open flame.

Slide the power "ON/OFF" switch

to the "OFF" position to conserve

Do not immerse probe handle or

TRACEABLE®
MINITHERMOMETER
INSTRUCTIONS