

---

# UHD51A

## Google Assistant Direct Commands

"Tell", "Ask" or "Speak" may be used when calling the apps invocation name (e.g. Hey Google, Ask Optoma SmartProjection to turn on living room). "Living Room" should be substituted for the device alias chosen during the Smart Home Projector Pair Code process.

> Hey Google, tell Optoma SmartProjection to turn on living room.

> Hey Google, tell Optoma SmartProjection to turn off living room.

> Hey Google, tell Optoma SmartProjection to increase volume on living room.

> Hey Google, tell Optoma SmartProjection to decrease volume on living room.

> Hey Google, tell Optoma SmartProjection to change volume to 8 on living room" (volume range is 1-10).

> Hey Google, tell Optoma SmartProjection to change input to HDMI 1 on living room.

> Hey Google, tell Optoma SmartProjection to change input to HDMI 2 on living room.

## UHD51A

### Google Assistant Commands

Hey Google, tell Optoma SmartProjection to  
> change input to Multimedia on living room” (to go home screen).

> Hey Google, tell Optoma SmartProjection to change input to VGA on living room.

Hey Google, tell Optoma SmartProjection to  
> change Display Mode to Cinema on living room.

> Hey Google, tell Optoma SmartProjection to change Display Mode to HDR SIM on living room.

Hey Google, tell Optoma SmartProjection to  
> change Display Mode to Game on living room.

> Hey Google, tell Optoma SmartProjection to change Display Mode to Reference on living room.

# UHD51A

## Google Assistant Commands

Hey Google, tell Optoma SmartProjection to  
> change Display Mode to Bright on living room.

Hey Google, tell Optoma SmartProjection to  
> change Display Mode to User on living room.

Hey Google, tell Optoma SmartProjection to  
> change Display Mode to ISF Day on living room.

Hey Google, tell Optoma SmartProjection to  
> change Display Mode to ISF Night on living room.

Hey Google, tell Optoma SmartProjection to  
> change HDR Picture Mode to Bright on living room.

Hey Google, tell Optoma SmartProjection to  
> change HDR Picture Mode to Standard on living room.

# UHD51A

## Google Assistant Commands

Hey Google, tell Optoma SmartProjection to  
> change HDR Picture Mode to Detail on living room.

Hey Google, tell Optoma SmartProjection to  
> change HDR Picture Mode to Film on living room.

Hey Google, tell Optoma SmartProjection  
> to change PureMotion to Low on living room.

Hey Google, tell Optoma SmartProjection to  
> change PureMotion to Medium on living room.

Hey Google, tell Optoma SmartProjection to  
> change PureMotion to High on living room.

Hey Google, tell Optoma SmartProjection to  
> change PureMotion to Off on living room.

## Google Assistant Commands 4K UHD/1080p USB Media Player

- Hey Google, tell Optoma SmartProjection to play on living room. (playback start with first video/audio file on the USB disk/drive).
- Hey Google, tell Optoma SmartProjection to pause on living room.
- Hey Google, tell Optoma SmartProjection to stop on living room.
- Hey Google, tell Optoma SmartProjection to next on living room.
- Hey Google, tell Optoma SmartProjection to previous on living room.
- Hey Google, tell Optoma SmartProjection to Fast Forward on living room.

## Google Assistant 4K UHD/1080p USB Media Player Commands

> Hey Google, tell Optoma  
SmartProjection rewind living room.

Hey Google, tell Optoma SmartProjection  
> start over living room (restart playback from  
beginning of USB disk/drive).

## Google Assistant Conversation Mode

To use Conversation Mode, simply say "Hey  
> Google, talk to Optoma SmartProjection" or  
"Hey Google, ask Optoma SmartProjection to  
help me".

> Sample Conversation:

User: "Hey Google, talk to Optoma  
SmartProjection".

Optoma SmartProjection: Hello.

User: Change Input Source.

Optoma SmartProjection: There are 4 input source options: HDMI1, HDMI2, VGA and Multimedia. Which input source would you like?

User: HDMI 2.

Optoma SmartProjection: What is the name of the projector?

User: Living room.

Optoma SmartProjection: Changing input to HDMI 2, is there anything else?

User: No.

Optoma SmartProjection: Alright.

## Google Assistant - Help Me

User: "Hey Google, Ask Optoma SmartProjection to help me."

Optoma SmartProjection: To change the volume, say "change volume to 3 on living room". In the aforementioned example, living room is the projector name, please substitute living room for the projector name you chose during setup of your Optoma Smart Home projector. For more information, simply say "More Information".

## Google Assistant Conversation Mode - More Information

To use the More Information command see the > example below:

> Sample Conversation:

User: "Hey Google, talk to Optoma SmartProjection"

Optoma SmartProjection: Hello.

User: More Information



Optoma SmartProjection: The Optoma SmartProjection Action for Google Assistant enables voice control of the following Optoma Smart Home Projector functions: Power, Volume, Brightness, Input Source, Media Player, Display Mode, HDR Picture Mode, and PureMotion. For example, if you want to change the Input Source, try saying “change input to HDMI 2 on living room”. To change the display mode, try saying “change Display mode to cinema on living room. In the aforementioned examples, living room is the projector name, please substitute living room for the projector name you designated during setup of your Optoma Smart Home Projector. This command structure applies to all Optoma Smart home Projector functions. So, what would you like me to do?

User: Change HDR Picture Mode.

Optoma SmartProjection: There are four HDR Picture modes: Bright, Standard, Detail and Film. Which HDR Picture mode would you like?

User: Bright

Optoma SmartProjection: What is the name of the projector?

User: Living room.

Optoma SmartProjection: Changing HDR Picture mode to bright on living room. Is there anything else you want me to do?