

GB-MBX200/210/220/230 Installation Instructions



The GB-MBX200 Medium Equipment Storage GearBox[™] provides 13.25" x 11.25" x 3" of storage space and is big enough to house laptops, digital signage players, switchers and equipment of similar size. It mounts to a variety of Premier Mounts' adapters (sold separately) using it's variety of mounting patterns. The GB-MBX210 comes complete with a PSD-SPA, the GB-MBX220 includes a PSP-SPA and the GB-MBX230 is designed to be mounted to the back of an ECM flat-panel ceiling mount.

Step 1

The GB-MBX200 may be used with a variety of Premier Mounts installation adaptors, such as PSD-SPA, PSP-SPA, etc. The included 100x100mm VESA bolt pattern may be used when mounting directly to the back of a flat-panel display (additional hardware and adapters may be required).



Step 2

- Your order should have come in two boxes. Remove the PSD-SPA from the second box.
- Locate the 4½" bolt pattern on the back of the GearBox™, which is highlighted in the drawing to the right.
- Install the PSD-SPA to the GB-MBX210 using the manual provided with the PSD-SPA.




The (4) hex bolts included with the PSD-SPA should be installed from within the GB-MBX210 and come out to meet the adaptor.

· All trademarks are the property of the respective trademark owners.



3130 East Miraloma Avenue Anaheim, CA 92806 USA <u>USA and Canada</u> Phone: 1.800.368.9700 Fax: 1.800.832.4888

Other Locations - Phone: (001).714.632.7100; Fax: (001).714.632.1044 ©Premier Mounts 2011




Step 3

- Your order should have come in two boxes. Remove the PSP-SPA from the second box.
- Locate the 4½" bolt pattern on the back of the GearBox[™], which is highlighted in the drawing to the right.
- Install the PSP-SPA to the GB-MBX220 using the hardware and manual provided with the PSP-SPA.

The (4) hex bolts included with the PSP-SPA should be installed from within the GB-MBX210 and come out to meet the adaptor.

Step 4

- Align the adjustable mounting slots of the GB-MBX230 with the fixed mounting holes on the ECM Mount you have purchased.
- Use the included (4) M6 x 16mm hex screws to attach the box to the back of ECM.
- Install screws from the inside of GearBox[™], screwing out into the
- ECM's mounting holes. The lid of the GearBox™ should be opened or removed prior to
- installation. Use the four (4) points marked A or the (4) marked B, depending on preferred orientation



PSP-SPA

Touchboards

205 Westwood Ave, Long Branch, NJ 07740 Phone: 866-94 BOARDS (26273) / (732)-222-1511 Fax: (732)-222-7088 | E-mail: sales@touchboards.com