
Storage GearBox™ for CTM-MS2 Tilting Mount - Installation Instructions

PC

Introduction



The storage GearBox[™] for the CTM-MS2 tilting mount (GB-MS2) securely holds a PC tower or similar-sized A/V equipment in between the flat-panel and mount. This space-saving feature helps efficiently organize your A/V installation for many applications, such as digital signage or corporate use. The GB-MS2 is a great alternative to storing electronics in false ceilings or bulky floor boxes.

Step 1

Follow the instructions in the CTM-MS2 manual up to page 7.


Stop at the end of the manual's "Installing the Wall Plate" section.


Step 2 Insert a PC tower or similar-sized A/V equipment into the media box.

Step 3


ЧШ

- 1) Insert the media box between the brackets and the wall plate.
- Hook the media box on the top rail of the wall plate.





Step 4




Step 5


Is the mounting pattern on the flat-panel wider than the media box?

If Yes, do not use the horizontal support brackets. Skip to Step 7.

If No, continue to Step 6.

· All trademarks are the property of the respective trademark owners.





Step 8

Once the flat-panel is hung, route cables and electrical wiring through the openings in the CTM-MS2 and media box.

