


**QLCS INSTALLATION INSTRUCTIONS**




**WARNING**

THE MAXIMUM LOAD WEIGHT PER BRAIDED CABLE IS 75LBS. DO NOT HANG OR ATTACH MORE THAN THE MAXIMUM LOAD WEIGHT. THE ATTACHMENT SURFACE AREAS MUST BE CAPABLE OF SUPPORTING EACH BRAIDED CABLE. IF NOT, THE SURFACE STRUCTURE MUST BE REINFORCED. PROPER INSTALLATION PROCEDURE BY A QUALIFIED SERVICE TECHNICIAN, AS OUTLINED IN THE INSTALLATION INSTRUCTIONS, MUST BE ADHERED TO. FAILURE TO DO SO COULD RESULT IN SERIOUS PERSONAL INJURY, OR EVEN DEATH.



Feed braided cable into the Quick Lock (see directional input arrows). To release the braided cable, slide the release pin to disengage (please see figures below).



- Step 1.** Loop the braided cable around, or through, the mounting structure.
- Step 2.** Run the open end through the loop.
- Step 3.** Pull the open end down until the braided cable tightens around the mounting structure.

