

TE Touch Solutions Technical Support
Online self-help:
www.elotouch.com/go/websupport

Technical Support contacts in your region:
www.elotouch.com/go/contactsupport

North America
TE Touch Solutions
301 Constitution Drive
Menlo Park, CA 94025
www.elotouch.com

Europe
Tel +32 (0)16 35 21 00
Fax +32 (0)16 35 21 01
elosales@elotouch.com

Asia-Pacific
Tel +81 (45) 478-2161
Fax +81 (45) 478-2180
www.tps.co.jp

Latin America
Tel 1-305-428-5210
Fax 1-305-717-4909
www.elotouch.com.ar



Quick Installation Guide

LCD Touchmonitor

Touchboards

205 Westwood Ave, Long Branch, NJ 07740

Phone: 866-94 BOARDS (26273) / (732)-222-1511

Fax: (732)-222-7088 | E-mail: sales@touchboards.com

DISCLAIMER:

Tyco Electronics Corporation and its Affiliates in the TE Touch Solutions business unit of the TE Connectivity Ltd. family of companies (collectively "TE") reserves the right to change or update, without notice, any information contained herein; to change, without notice, the design, construction, materials, processing or specifications of any products; and to discontinue or limit production or distribution of any products.

No part of this publication may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language or computer language, in any form or by any means, including, but not limited to, electronic, magnetic, optical, chemical, manual, or otherwise without prior written permission of Tyco Electronics Corporation.

Elo (logo), Elo TouchSystems, TE Connectivity, TE connectivity (logo) and TE (logo) are trademarks of the TE Connectivity Ltd. family of companies.

Copyright 2011 Tyco Electronics Corporation, a TE Connectivity Ltd. Company. All rights reserved. [04/21/2011].




Revision A
P/N E893866



www.elotouch.com



① Power



No touch driver installations needed

Aucune installation de pilote nécessaire tactile

No hay instalaciones de controlador toque necesario

Kein Touch-Treiber-Installationen notwendig

Nessun driver installazioni tocco necessario

Не прикасаться установок драйвера необходимы


タッチドライバをインストール不要

不需安裝觸摸驅動程序

不需安裝觸控驅動程式

필요 없음 터치 드라이버 설치 없음

② Video



③ Touch

