
## **SMART Board® MX (V2)**

### Turn on the display

To wake the display, press the Power button U on the front control panel.

To return the display to sleep, press the Power button  $\ensuremath{\textbf{U}}$  again.



#### Write and erase on the display

Pick up one of the display's pens and use it to write or draw in digital ink.

Move your fist or palm over the digital ink you want to erase.




# Show the connected computer's desktop

After connecting a computer, press the Input Select button on the front control panel, and then tap the computer's thumbnail:



**Note:** Be sure to enable touch control of your computer by connecting a USB cable from the computer to the appropriate USB-B receptacle on the display.



#### Use the iQ features

The display includes iQ features that you can use without connecting a computer. To access these features, press the Home button  $\widehat{\mathbf{w}}$  on the front control panel.

You can then use all the iQ features described in the SMART Board display teacher guide (smarttech.com/displayteacherguide).



