



TO LIGHT GREEN OR AMBER LED WHEN ACTIVE




TO LIGHT RED LED WHEN ACTIVE



TO LIGHT THE GREEN LED FOR ACTIVE AND RED LED FOR MUTE

TWO OUTPUTS REQUIRED PER MIC JACK



Touchboards

205 Westwood Ave, Long Branch, NJ 07740
Phone: 866-94 BOARDS (26273) / (732)-222-1511
Fax: (732)-222-7088 | E-mail: sales@touchboards.com