

TIP & TOOL STAND KITS INSTALLATION INSTRUCTION MANUAL Part Number 5050-0570 REV. B

PACE Tip & Tool Stands may be installed in any of the following configurations:

- 1. The Tip & Tool Stand may be used as a free standing unit and placed in any location adjacent to the PACE power source.
- 2. Stand/Stand Mounting Tip & Tool Stands may be connected to each other.
- Power Source Mounting The Tip & Tool Stand may be attached to either side of any PACE system

Power Source Mounting - Attach the stand to the power source, using the following procedure:


- 1. Insert the 2 enclosed hex head mounting screws into the slot on the side of the power source extrusion.
- 2. Position the mounting screws to the rear of the power source and spaced approximately 1 inch apart to line up with the mounting holes on the side of the tip and tool stand.
- 3. Place the Tip & Tool Stand beside the power source. Insert ends of the 2 mounting screws into the 2 adjacent Tip & Tool Stand mounting holes.
- 4. Install a thumb nut onto the end of each mounting screw from the inside of the tool stand and tighten the thumb nuts.


Stand to Stand Mounting - Tip & Tool Stands may be attached together using the following procedure:

- 1. Place the 2 stands beside each other,
- 2. Insert the 2 mounting screws through matching mounting holes in the stands
- 3. Secure with the 2 thumb nuts.

HANDPIECE	PART NUMBER
TD-100	6019-0079-P1
MT/TP-100	6019-0080-P1
PS-90/TJ-85	6019-0081-P1
SX-90/SX-70/TP-65/TJ-70	6019-0082-P1
TT-65	6019-0083-P1

CONSUMABLES	PART NUMBER
Sponge, Tip and Tool Stand	4021-0013-P3
Brass Tip Cleaner	1129-0018-P1
Nut, Thumb 8/32 Black	1410-0095-P5
Screw Hex, 8/32X.50 SSNAHX	1405-0648-P5







PACE Incorporated 255 Air Tool Drive Southern Pines, North Carolina, 28387 Tel: (877) 882-PACE

Tel: (910) 695-7223 Fax: (910) 695-1594 Pace Europe 11 Holdom Avenue Bletchley, Milton Keynes, United Kingdom, MK1 1QU Tel: 011 44 1908 277666

Fax: 011 44 1908 277777