# VM7514/VM8514

# 4-Port HDBaseT Input/Output Board Quick Start Guide

## **Package Contents**

- 1 VM7514 4-Port HDBaseT Input Board, or
- 1 VM8514 4-Port HDBaseT Output Board
- 4 Terminal Block Connectors
- 1 IR Transmitter
- 1 IR Receiver
- 1 User Instructions

## VM7514 Front View

# **5 1 1 2 3 4**

## VM8514 Front View



## **Hardware Review**

## VM7514 Front View

- 1. HDBaseT Input Ports
- 2. IR Ports
- 3. RS-232 Ports
- 4. Status LED
- 5. HDBaseT Port LED

## VM8514 Front View

- 1. HDBaseT Output Ports
- 2. IR Ports
- 3. RS-232 Ports
- 4. Status LED
- 5. HDBaseT Port LED



205 Westwood Ave, Long Branch, NJ 07740 Phone: 866-94 BOARDS (26273) / (732)-222-1511 Fax: (732)-222-7088 | E-mail: sales@touchboards.com

**Note:** The HDBaseT Port LED lights orange to indicate there is no connection and lights green to indicate the system is receiving power.


# **Hardware Setup**

### I/O Board Installation


1. (Optional) Power off the Modular Matrix switch. **Note:** The VM1600 I/O boards are hot swappable.

2. 2. On the rear of the VM1600 unscrew the two Phillips head screws and remove the back panel cover.


**Note:** The four upper slots are for input boards; the four lower slots are for output boards.



3. Slide the I/O board into the open slot on the VM1600 until it secures in place.




4. Tighten the two screws on the I/O board to fasten it to the Modular Matrix switch, until it's secured to the unit.



- 5. Repeat the steps if you are installing additional I/O boards.
- 6. (Optional) Power on the Modular Matrix switch.

## **Device Installation**

- 1. Using HDMI Cable connect the video sources to the HDMI Input Port on the HDBaseT Transmitter.
- 2. Connect the RS-232 Port and HDBaseT Output Port on the HDBaseT Transmitter to the VM7514 HDBaseT Input Port and RS-232 Port.
- 3. Connect the RS-232 Port and HDBaseT Input Port on the HDBaseT Receiver to the VM8514 HDBaseT Output Port and RS-232 Port
- 4. Using HDMI Cable connect the display device to the HDMI Output Port on the HDBaseT Receiver.
- 5. Connect the IR transmitter/receiver to the IR port on the VM7514/VM8514.
- 6. (Optional) Power on the Modular Matrix Switch and all devices.



Note: To use the Seamless Switch™ and Video Wall functionalities, please check the firmware version of the VM8514 and VE805R are the most current available. To download the most up to date firmware for your device, visit the product's page on our website: www.aten.com.

#### Important Notice

Considering environmental protection, ATEN does not provide a fully printed user manual for this product. If the information contained in the Quick Start Guide is not enough for you to configure and operate your product, please visit our website www. aten.com, and download the full user manual.

## **Online Registration**

http://eservice.aten.com

## **Technical Phone** Support

International: 886-2-86926959

## North America:

1-888-999-ATEN Ext: 4988

## **United Kingdom:**

44-8-4481-58923



This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired

The following contains information that relates to China:



#### **EMC Information**

FEDERAL COMMUNICATIONS COMMISSION INTERFERENCE STATEMENT:
This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this

CE Warning: This is a class A product. In a domestic environment this product may cause radio interference in which case the user may be required to take

Suggestion: Shielded twisted pair (STP) cables must be used with the unit to ensure compliance with FCC & CE standards.

All information, documentation, firmware, software utilities, and specifications contained in this package are subject to change without prior notification by the manufacturer. Please visit our website http://www.aten.com/download/?cid=dds for the most up-to-date versions.

© Copyright 2015 ATEN® International Co., Ltd.

ATEN and the ATEN logo are trademarks of ATEN International Co., Ltd. All rights reserved. All other trademarks are the property of their respective owners

This product is RoHS compliant.