



ViewSplit (Monitor Screen Split Software) User Guide

ViewSplit is a Windows application used to manage a ViewSonic Display to manual adjustment of the window organization. **ViewSplit** allows the selected ViewSonic monitor's desktop to be organized into various predefined or customizable windows layouts and automatically to fill specific regions within a window layout.

■ How to Install


Visit the ViewSonic website (www.viewsonic.com) and download the latest software for your monitor. This software has been designed specifically for ViewSonic monitors only.

■ How to Use

1. Connect the **ViewSonic** monitor and then double-click on the **ViewSplit** shortcut icon on the desktop, or click on the notification tray icon.



2. Select a predefined template.



3. The screen split layout is applied.
4. Open windows dragged into each zone will position and resize automatically.




ViewSplit (Monitor Screen Split Software) User Guide

5. To create a customizable template:

5.1 Click the **Manual Adjust** icon:



5.2 Select a predefined template and then drag the Red-Line for the new custom layout.



5.3 Click Save icon, the size and position of the windows is saved as a customizable template layout.



Save

6. To delete a customizable template:

6.1 Click the **Manual Adjust** icon:




6.2 Select a customizable template.

6.3 Click Delete icon, the selected customizable template is deleted.



Delete

7. Mini-View User Interface:



When a template is selected, ViewSplit Mini-View User Interface at the bottom right of the screen is pop out.

Click the Home icon can return to the main ViewSplit User Interface.

